
Ignition battery
Ignition switch
Choke servomotor
Throttle servomotor
Power supply of ignition
IGNITION 1
Engine
RX
Fully Y cable for information about RPM from ignition.
You must not use this Y cable. Relay will working with out information about RPM – non functional blocking of relay during running engine
RX battery
Starter battery
Start relay
Starter